

Allowable NCE cab addresses by system type - highlighted addresses are given priority

Address	PowerPro	PowerPro Radio	PowerCab V1.28	SB3/SB3a V1.28	PowerCab V1.65	SB3a/SB5 V1.65
1	Any but Cab04/05					
2	Any	ProCab or Intermediate	Base PowerCab	Any	Base PowerCab	Any
3	Any	ProCab or Intermediate	Any	Any	Any	Any
4	Any	ProCab or Intermediate	Any	Any	Any	Any
5	Any	ProCab or Intermediate		Any	Any	Any
6	Any	ProCab or Intermediate				Any
7	Any	ProCab or Intermediate				Any
8 - 10	Any	ProCab or Intermediate			Accessories	Accessories
11 - 14	Any	ProCab or Intermediate				
15	Any	ProCab or Intermediate				
16 - 20	Any	ProCab or Intermediate				
21	Any	Intermediate Only				
22 - 25	Any	Intermediate Only				
26	Any	Intermediate Only				
27	Any	Intermediate Only				
28 - 41	Any	Intermediate Only				
42	Any	Intermediate Only				
43 - 49	Any	Intermediate Only				
50 - 63	Any					